



ADVANCED TEMPERATURE CONTROL

1416 GRAHAM'S LANE, BURLINGTON, ONTARIO L7S 1W3

TEL: (905) 637-3468

FAX: (905) 637-3363

Introduction

This document shows how to change the **M910166 (Control + Mounting Bracket)** to the **M910165 (Only Control)**.

Instructions:

1. Use an appropriate cross head screwdriver to remove the 4 screws indicated in the first figure below.
2. Remove and discard the mounting bracket and the 4 screws from the product.
3. Insert the plastic box and use an appropriate cross head screwdriver to insert the 04 new screws (2,5 x 6mm) into the plastic box indicated in the third figure below.



EZ TWISTER



BASIC TWISTER